## **Zippkits Glue Caddy**

We recommend white glue for assembly. You can use Elmer's, Titebond I, etc. If you use CA, you risk the parts curing before you can align them.

Assemble the Glue Caddy beginning with the base, then the ends and so forth. The Ends are cut so that the "Z" reads facing out.

Tape the assembly for a few hours to cure. Seal with any kind of sealer if you prefer.

